

Bedienungs- anleitung	User manual		
	Einbau-Herd	Built-under oven	
ZOU 592			,

## Inhaltsverzeichnis

Warnungen und wichtige Hinweise	3
Gerätebeschreibung	
Bedienelemente	6
Bedienungsknebel für Kochmulde	g
Erstinstallation	10
Programmieren des Ofens	11
Sonderfunktionen	
Back- und Bratbleche	21
Reinigung und Wartung	23
Wenn etwas falsch läuft	27
Technische Daten	28
Anweisungen für den Installateur	29
Elektroanschluss	29
Einbau-Anweisungen	31

# Anleitung zur Gebrauchsanweisung



Sicherheitsanweisung



Schritt-für-Schritt-Anweisung



Praktische Tipps



- Dieses Gerät entspricht den folgenden **EWG-Richtlinien**: 2006/95 (Niederspannungsrichtlinie);
  - 2004/108 (EMC- Richtlinie); und folgenden Zusätzen und Änderungen.

## Deutsch

# Marnungen und wichtige Sicherheitshinweise

Heben Sie auf jeden Fall die mit diesem Gerät gelieferte Gebrauchsanweisung auf. Sollte das Gerät an Dritte abgegeben oder verkauft werden, oder falls Sie das Gerät bei einem Umzug in der alten Wohnung lassen, ist es von größter Wichtigkeit, dass der/die neue Nutzer(in) über diese Gebrauchsanweisung und die Hinweise verfügen kann.

Diese Hinweise dienen der Sicherheit des Nutzers und seiner Mitbewohner. Lesen Sie sie also aufmerksam, bevor Sie das Gerät anschließen und/oder in Gebrauch nehmen.

#### Aufstellung

- Die Installation muss von fachkundigem Personal vorgenommen werden, unter Beachtung der bestehenden Vorschriften. Die einzelnen Installationsarbeiten sind unter den Hinweisen für den Installateur beschrieben.
- Lassen Sie die Installation und den Anschluß von einem Fachmann, gemäß den ihm dank seiner Fachkenntnis bekannten Richtlinien ausführen.
- Auch gegebenenfalls auf Grund der Installation erforderliche Modifikationen an der Stromversorgung haben durch einen Fachmann zu erfolgen.
- Dieser Backofen wurde je nach Ausführung als Einzelgerät oder als Kombinationsgerät mit Elektroplatte für den Anschluß an jeweils 1,2 oder 3 Phasen (oder Gruppen) an 230 V hergestellt. Der Anschluß an mehr Phasen ohne Nulleiter (400 V) führt zu Zerstörung des Ofens und der angeschlossenen Kochplatten.

#### **Betrieb**

- Dieser Backofen ist zur Zubereitung von Speisen gedacht; gebrauchen Sie ihn niemals zu Anderem.
- Beim Öffnen der Backofentür, während oder am Ende des Garens auf den Heißluftstrom achten, der aus dem Backofen austritt.
- Beim Herdbetrieb mit erhöhter Vorsicht vorgehen.
   Durch die starke Hitze der Heizstäbe sind Rost und sonstige Teile sehr heiß.

- Falls Sie aus welchen Gründen auch immer -Alufolie zur Zubereitung von Speisen im Backofen verwenden sollten, lassen Sie diese nie in direkten Kontakt mit dem Boden des Backofens kommen.
- Gehen Sie bei der Reinigung des Backofens vorsichtig vor: sprühen Sie nie auf den Fettfilter (falls vorhanden), die Heizstäbe und den Thermostatfühler.
- Es ist gefährlich, Veränderungen jeglicher Art an diesem Gerät oder an seinen Eigenschaften vorzunehmen.
- Während des Back-, Brat- und Grillvorgangs werden das Backofenfenster und die übrigen Geräteteile heiß. Kinder sollten daher von dem Gerät ferngehalten werden. Bei Anschluss von Elektrogeräten an Steckdosen in Backofennähe ist darauf zu achten, dass Anschlussleitungen nicht mit heißen Kochstellen in Berührung kommen oder in der heißen Backofentür eingeklemmt werden.
- Verwenden Sie immer Topfhandschuhe, um feuerfeste heiße Schüsseln oder Töpfe aus dem Backofen zu nehmen.
- Eine regelmäßige Reinigung verhindert die Verschlechterung des Oberflächenmaterials.
- Schalten Sie vor der Reinigung des Backofens entweder den Strom ab, oder ziehen Sie den Netzstecker.
- Stellen Sie sicher, dass sich der der Backofen in der Position «AUS» befindet, wenn er nicht mehr benutzt wird.

- Das Gerät darf nicht mit einem Heißdampf- oder Dampfstrahlreiniger gereinigt werden.
- Benutzen Sie keine Scheuermittel oder scharfe Metallschaber. Sie k\u00f6nnen die T\u00fcrscheiben verkratzen und dadurch zum Zerspringen der Scheiben f\u00fchren.

schen. Umwelt und Gesundheit werden durch falsches Entsorgen gefährdet. Weitere Informationen über das Recycling dieses Produkts erhalten Sie bei Ihrem Rathaus, der Müllabfuhr oder dem Geschäft, in dem Sie das Produkt gekauft haben.


#### Kindersicherheit

- Dieses Gerät ist für den Gebrauch durch Erwachsene bestimmt. Es ist gefährlich, wenn Sie es Kindern zum Gebrauch oder Spiel überlassen.
- Halten Sie Kinder fern, solange der Backofen in Betrieb ist. Auch nachdem Sie den Backofen ausgeschaltet haben, bleibt die Tür noch lange heiß.
- Das Gerät darf von Kindern oder Personen, deren physische, sensorische oder geistige Fähigkeiten und deren Mangel an Erfahrung und Kenntnissen einen sicheren Gebrauch des Gerätes ausschließen, nur unter Aufsicht oder nach ausreichender Einweisung durch eine verantwortungsbewußte Person benutzt werden, die sicherstellt, dass sie sich der Gefahren des Gebrauchs bewusst sind

#### Kundendienst

- Lassen Sie Überprüfungsarbeiten und/oder Reparaturen vom Kundendienst des Herstellers oder von einem vom Hersteller autorisierten Kundendienst ausführen, und verwenden Sie nur Original-Ersatzteile.
- Versuchen Sie nicht, das Gerät bei Funktionsstörungen oder Schäden selbst zu reparieren. Durch Reparaturen seitens ungeschulter Personen können Schäden oder Verletzungen hervorgerufen werden.

Das Symbol auf dem Gerät bzw. auf dem Verpackungsmaterial weist darauf hin, dass es nicht über den normalen Hausmüll entsorgt werden darf. Es muss stattdessen an eine Sammelstelle für das Recycling von elektrischen und elektronischen Geräten übergeben werden. Durch Ihren Beitrag zum korrekten Entsorgen dieses Produkts schützen Sie die Umwelt und die Gesundheit Ihrer Mitmen-




- 1. Bedienungsblende
- 2. Knebel für Kochstelle vorne links
- 3. Knebel für Kochstelle hinten links
- 4. Elektronische Zeitschaltuhr
- 5. Knebel für Kochstelle hinten rechts
- 6. Knebel für Kochstelle vorne rechts

- 7. Luftschächte für Kühlungsventilator
- 8. Grillrost
- 9. Innenbeleuchtung
- 10. Umluft-/Heißluftgebläse
- 11. Typenschild

## Ofenzubehör



## Bedienungsblende



#### Drucktasten

- 1. FIN / AUS
- 2. Funktionswahlschalter
- 3. Schnelles Aufheizen
- 4. Taste zum Verringern des eingestellten Wertes "—" (Zeit oder Temperatur)
- 5. Taste zum Steigern des eingestellten Wertes "+" (Zeit oder Temperatur)
- 6. Programmierung von Kurzzeitwecker, Garzeit und Garzeitende

#### **ACHTUNG**

Bei Stromausfall bleiben die eingegebenen Daten etwa 3 Minuten lang im Speicher der Programmiereinheit gespeichert. Danach werden die Daten gelöscht und müssen neu eingegeben werden, wenn wieder Strom vorhanden ist.

Die Garfunktionen werden von einer elektronischen Programmiereinheit gesteuert.

Jede Art von Garfunktion, Gartemperatur und Garzeit kann ausgewählt werden.

### Sonderfunktionen

Folgende Funktionen können durch die gleichzeitige Betätigung von zwei Tasten ausgewählt werden:

Kindersicherheitssperre: die Tasten \_\_\_ und "\_\_\_" drücken:

Piep-Signal: die Tasten und "+" drücken;

**'Demo'-Funktion:** Die Tasten **(1**) und "**+**" drücken.

#### Ein- und Ausschalten des Ofens

Der Ofen muss eingeschaltet werden, bevor eine Funktion/ein Garprogramm ausgewählt werden kann.

Bei jeder Betätigung der Taste (1) erscheint das Symbol des Ofens auf dem Display und die Ofenbeleuchtung wird eingeschaltet.

Der Ofen kann in jedem Augenblick ausgeschaltet werden.

Zum Ausschalten des Ofens, die Taste ① betätigen: Alle Funktionen/Garprogramme werden abgebrochen, die Ofenbeleuchtung erlischt und auf dem Display erscheint die aktuelle Uhrzeit.

#### Auswählen einer Garfunktion

Den Ofen durch Betätigen der Taste ① einschalten.

Die Taste betätigen, um die gewünschte Funktion

auszuwählen. Bei jeder Betätigung der \_\_\_\_\_\_ Taste erscheint das Symbol der Garfunktionen auf dem Display und zeigt an, welche Funktion in jenem Augenblick aktiv ist. Neben dem Symbol der ausgewählten Garfunktion erscheint die entsprechende Nummer (Abb. 1).

Für jede Garfunktion erscheint auf dem Display der Temperaturen die eingestellte Temperatur. Sollte die eingestellte Temperatur nicht der gewünschten Temperatur entsprechen, die Tasten "\_\_\_" und "\_+" betätigen, um die Temperatur in 5 Stufen einzustellen.


- Das Symbol des Thermometers zeigt die Ofentemperatur an:


Wenn die Temperatur im Ofen den Wert der eingestellten Temperatur erreicht, ertönt ein akustisches Signal und das Symbol des Thermometers **A** hört auf zu blinken.

Liegt die Innentemperatur über der eingestellten Temperatur (z. B., wenn die Garfunktion beendet und der Ofen noch warm ist), so erscheint sie nicht auf dem Display.



Die Ofentür stets nur am Griff im mittleren Bereich anfassen.






## Ändern der Temperatur und der eingestellten Garzeit

Mit den Tasten "\_\_" oder "+" die eingestellte Temperatur ändern, während das Symbol "°" blinkt (Abb. 2).

Die programmierbare Höchsttemperatur beträgt 250 °C.


und Garzeitdauer verändern, während das Symbol blinkt (Abb. 2).



Die Symbole zeigen der Reihe nach die verfügbaren Garfunktionen an.



Heißluft - Die Hitze wird durch das Gebläse einheitlich verteilt. Die eingestellte Temperatur beträgt 175 °C.



Einfacher Grill - Die Ofenhitze kommt nur von oben. Die eingestellte Temperatur beträgt 250 °C.



Heißluftgrill - Die Hitze kommt nur von oben und wird vom Gebläse verteilt. Die eingestellte Temperatur beträgt 180 °C. Wählen Sie eine



Temperatur von höchstens 200 °C.



Pizza backen - Die kombinierte Wirkung der von unten kommenden Hitze und der vom Gebläse verteilten Heißluft ermöglicht das einheitliche Backen von Pizzas oder gesalzenen Torten. Die eingestellte Temperatur beträgt 175 °C.

Doppelter Grill - Der Ofen gibt starke Hitze nur von oben ab. Die eingestellte Temperatur beträgt 250 °C.

Unteres Garen - Der Ofen gibt eine mäßige Hitze nurvon unten ab. Die eingestellte Temperatur beträgt 250 °C.

Oberes Garen - Der Ofen gibt eine mäßige Hitze nur von oben ab. Die eingestellte Temperatur beträgt 250 °C.

Auftauen - Das Gebläse lässt die Luft im kalten Ofen kreisen und beschleunigt so das Abtauen tiefgefrorener Speisen.

# Bedienungsknebel für Kochmulde

### Versenkbare Knebel

Diese Modelle sind mit versenkbaren Knebeln ausgestattet. Diese Schalterknebel funktionieren nach dem Druck-Zug System. Sie können vollständig in die Blende versenkt werden, wenn der Backofen außer Betrieb ist

### Bedienungsknebel für Kochmulde

An der Schalterblende befinden sich die Schalt-Knebel für die vier Kochmulden-Heizelemente. Die Kochstellen werden mit einem 9-Takt-schalter geregelt, wovon die folgenden Arbeitsstufen benutzt werden können:

0 = AUS

1 = Minimum

9 = Maximum


### Zweikreis - Zuschaltung


(siehe die Liste der Geräte im Kapitel "Technische Daten")


Das Zuschalten beider Heizkreise erfolgt durch das Drehen des Kochzonenknebels von Stufe 9 auf Position

"(im Uhrzeigersinn); "Klick" ist hörbar. Beide Heizkreise sind jetzt gleichzeitig eingeschaltet. Anschließend wird die gewünschte Stufe eingestellt (Knebel gegen den Uhrzeigersinn drehen).

Die Zubereitung von Speisen mit Öl oder Fett wie z.B. pommes frites, darf nicht ohne Aufsicht geschehen, da Öle und Fette bei überhitzung leicht entflammen können







### **Erst-Installation**

Wenn der Ofen zum ersten Mal an das Stromnetz angeschlossen wird, erscheinen auf der Anzeige die

Zahlen "12.00" und das Symbol blinkt.

Um den Ofen in Betrieb nehmen zu können, muss die aktuelle Uhrzeit eingegeben werden.

#### Zum Einstellen der aktuellen Uhrzeit:

a) während das Symbol ▶ blinkt, die Uhrzeit mit den Tasten "—" oder "+" einstellen (Abb. 3). Das Symbol ▶ verschwindet etwa 5 Sekunden nach der letzten Einstellung (Abb. 4).

Dann wie unter Punkt "a" beschrieben fortfahren.



Entfernen Sie das gesamte Verpackungsmaterial innen und außen am Backofen, bevor Sie ihn in Betrieb nehmen.

Vor dem erstmaligen Gebrauch sollte der Backofen einmal aufgeheizt werden, ohne dass sich Lebensmittel darin befinden.



Dabei kann sich ein unangenehmer Geruch entwickeln. Das ist normal. Die Ursache sind Herstellungsrückstände.

Stellen Sie sicher, dass der Raum gut belüftet ist.

#### Nun:

- Den Ofen durch Betätigen der Taste () einschalten.
- Zweimal die Taste betätigen und die Funktion 'Herkömmliches Garen' auswählen.
- Mit der Taste "+" eine Temperatur von 250°C einstellen.
- Den LEEREN Ofen etwa 45 Minuten heizen. Sie können den Ofen auch für eine Zeit von 45 Minuten programmieren.
- Den Raum während dieser Zeit gut lüften.
  Es wird empfohlen, das oben beschriebenen Verfahren durch Auswählen der Garfunktion 'Doppelter Grill'
  sowie die Funktion 'Garen+Gebläse' (2) etwa 5-10 Minuten lang zu wiederholen.



Bevor man mit dem Garen beginnt, das ROST und die FETTPLATTE qut reinigen.








Abb. 4





## Programmieren des Ofens

### Verwendung der Kochuhr

- Die Taste 🗗 zum Aktivieren der Funktion drücken

Kochuhr (Abb. 7). Das Symbol fängt an zu blinken und auf dem Display erscheinen die Zahlen "0.00"

- Nach Einstellen der Garzeit wartet die Kochuhr 3 Sekunden, dann beginnt der Zeitablauf (Abb. 8).
- Nach Ablauf der eingestellten Zeit ertönt ein Signalton.
   Zum Abstellen des Signaltons eine beliebige Taste drücken.



Achtung: Die Funktion Kochuhr schaltet den Ofen NICHT automatisch aus, wenn er in Betrieb ist.






Abb. 8

### Ändern der Einstellungen der Kochuhr

Die Taste 🗘 betätigen bis die zwei Symbole 🦳 und


▶ auf dem Display blinken. Nun mit "—" oder "+" die Einstellung ändern.

### Löschen der Einstellungen der Kochuhr:

Die Taste 🕘 betätigen bis die zwei Symbole 🛕 und

▶ auf dem Display blinken.

Die Taste "\_\_\_" drücken, bis auf dem Display die Zahlen "0.00" erscheinen (Abb. 9).





## Programmierung der Ofenausschaltung


- Stellen Sie die zu garende Speise in den Ofen, wählen Sie die Garfunktion und die gewünschte Temperatur aus (Abb. 10).
- Die Taste 🗗 zum Aktivieren der Funktion drücken
- "Garzeit" (Abb. 11). Das Symbol "Garzeit"  $\rightarrow$  blinkt und auf dem Display erscheinen die Zahlen "0.00".
- Mit der Taste "♣" die gewünschte Zeit einstellen, während das Symbol ▶ blinkt. Die einstellbare Höchstzeit beträgt 23 Stunden und 59 Minuten.
- Nach Einstellen der Garzeit wartet die Programmiereinheit 3 Sekunden, dann beginnt der Zeitablauf.
- Nach Ablauf der eingestellten Zeit schaltet sich der Ofen automatisch aus und ein Signalton ertönt. Auf dem Display erscheinen die Zahlen "0.00".
- Zum Abstellen des Signaltons eine beliebige Taste drücken.

#### Zum Löschen der Garzeit:

- Die Taste "\_\_\_" drücken, bis auf dem Display die Zahlen "0.00" erscheinen (Abb. 12).











# Programmierung der Ofenein- und - ausschaltung

- Die "Garzeit" wie auf der vorherigen Seite beschrieben einstellen.
- Die Taste drücken und Funktion "Garzeit" auswählen; das entsprechende Symbol  $\rightarrow$  fängt zu blinken an. Auf dem Display erscheint nun das Ende der Garende (d. h. die aktuelle Uhrzeit plus die eingestellte Garzeit Abb. 13).



- Nach Einstellen der Garzeit wartet die Programmiereinheit 3 Sekunden, dann beginnt der Zeitablauf.
- Der Ofen schaltet sich automatisch ein und aus, das Ende der Garzeit wird von einem Signalton gemeldet.
   Zum Abstellen des Signaltons eine beliebige Taste drücken.

Zum Löschen der Garzeit, die auf der vorherigen Seite angegebenen Anleitungen befolgen.



## Sonderfunktionen

### Vollautomatisches Ausschalten

Sollten Sie vergessen, Ihren Ofen auszuschalten, schaltet diese Funktion ihn automatisch je nach der eingestellten Temperatur nach einer gewissen Zeit aus (Abb. 14).



Abb. 14

Beträgt die Temperatur:	schaltet der Ofen sich aus nach:
250°C	3 Stunde
von 200°C bis 245°C	5,5 Stunden
von 120°C bis 195°C	8,5 Stunden
weniger als 120°C	12 Stunden



### Nutzung der Restwärme

Programmieren Sie das vollautomatische Ausschalten des Ofens, schaltet sich dieser tatsächlich einige Minuten vor dieser eingestellten Zeit aus. Auf diese Weise wird die Restwärme im Ofen zum vollständigen Garen der Speisen genutzt und ermöglicht so eine Energieeinsparung. Die Meldungen auf dem Display werden bis zum Ende der eingestellten Garzeit angezeigt.

Diese Sonderfunktion ist nicht aktiv, wenn die eingestellte Garzeit weniger als 15 Minuten beträgt.

### Kindersicherheitssperre


Die Ofensteuerungen können gesperrt werden, um das Einschalten durch Kinder beim Spielen zu vermeiden.

- Ist der Ofen eingeschaltet, schalten Sie ihn mit Hilfe der Taste ① aus.
- Drücken Sie gleichzeitig die Tasten \_\_\_\_ und "\_\_\_" und halten Sie sie mindestens 3 Sekunden lang gedrückt. Man hört einen kurzen Signalton und auf dem Display erscheint die Anzeige 'SAFE' (Abb. 15).
- Der Ofen ist nun gesperrt. Nun kann keine Garfunktion ausgewählt werden.

#### Um die Sperre aufzuheben:

- Drücken Sie gleichzeitig die Tasten \_\_\_\_ und "\_\_\_" und halten Sie sie mindestens 3 Sekunden lang gedrückt. Ein kurzer Signalton ertönt und die Anzeige 'SAFE' verschwindet vom Display; der Ofen kann nun wieder benutzt werden (Abb. 16).





#### Schnellheizfunktion

Nach der Auswahl der gewünschten Garfunktion und der Einstellung der Gartemperatur, heizt der Ofen bis die gewünschte Temperatur erreicht wird.

Die Aufheizzeit des Ofen dauert etwa 10-15 Minuten, je nach der ausgewählten Garfunktion und der eingestellten Temperatur.

Soll die eingestellte Temperatur in kürzerer Zeit erreicht werden, kann man die Funktion 'Schnellheizen' wählen.

- Den Ofen durch Betätigen der Drucktaste 
   einschalten:
- Die Garfunktion gemäß der Anleitungen hier oben auswählen:
- Stellen Sie die Temperatur mit den Tasten "\_\_"
  und "+" ein. Die Temperaturanzeige blinkt auf
  dem Display;
- 4) Drücken Sie die Taste **B**. Die Schrift "FHU" erscheint auf dem Display (Abb. 17).
- 5) Beim Drücken der Taste \_\_\_\_, blinkt das Symbol der eingestellten Temperatur "°" etwa 10 Sekunden lang, und zeigt so an, dass die Temperatur mit den Tasten "\_\_\_" und "+" noch genauer eingestellt werden kann.
- 6) Wenn die Temperatur des Ofens den eingestellten Wert erreicht, lässt die Programmiereinheit einen kurzen Signalton ertönen und die eingestellte Temperatur wird auf dem Display angezeigt.

Diese Funktion kann bei der Auswahl jeder Garfunktion und Temperatur verwendet werden.



#### Demofunktion

Dieser Modus dient den Fachgeschäften zur Vorführung der Backofenfunktionen ohne Stromverbrauch, abgesehen von der Innenbeleuchtung, dem Display und dem Gebläse. Diese Funktion lässt sich nur bei Erstanschluß einschalten.

Bei einem Stromausfall, wenn die Stromversorgung wiederhergestellt wird, lässt sich die Demofunktion, nur wenn im Display automatisch die Angabe 12:00 und das Symbol (4) blinkt, einschalten.

- 1. Berühren Sie die Taste etwa 2 Sekunden lang. Ein kurzer Signalton ist zu hören.
- 2. Berühren Sie gleichzeitig die Tasten 4 und "—". Ein kurzer Signalton ist zu hören, auf dem Display erscheint die Ührzeit 12:00 angegeben (Abb. 18).

Beim Einschalten des Backofens erscheint das Symbol

auf dem Display, das bedeutet daß die Demofunktion aktiviert ist.


Alle Funktionen des Backofens können ausgewählt werden.

Der Backofen ist nicht wirklich in Betrieb und die Heizelemente schalten sich nicht ein.

Schalten Sie den Ofen ab und gehen Sie wie oben beschrieben vor, um den Demobetrieb wieder auszuschalten.



Die Demofunktion bleibt bei Stromausfall im Programm gespeichert.



#### **Fehlercode**

Die elektronische Programmiereinheit führt ständig einen Diagnosetest des Systems durch. Sind einige Parameter nicht korrekt, z. B. aufgrund der nicht korrekten Verwendung des Ofens, stellt die Steuereinheit die aktuellen Funktionen aus und auf dem Display erscheint der entsprechende Fehlercode ("F" gefolgtvon Ziffern).



#### Sicherheits-Thermostat

Um gefährliche Überhitzung zu vermeiden (durch unsachgemäßen Gebrauch des Gerätes oder defekte Bestandteile), ist der Backofen mit einem Sicherheits-Thermostat ausgestattet, welcher die Stromversorgung unterbricht. Die Wiedereinschaltung erfolgt automatisch bei Temperaturabfall.

Sollte der Sicherheits-Thermostat aufgrund unsachgemäßen Gebrauchs des Gerätes ansprechen, genügt es, nach der Abkühlung des Backofens die Fehlerursache zu beseitigen. Spricht dagegen der Thermostat wegen eines defekten Bauteiles an, so wenden Sie sich bitte an den Kundendienst.

#### Kühlventilator

Der Kühlventilator kühlt den Backofen und das Bedienfeld. Der Ventilator springt automatisch an, wenn der Backofen einige Minuten in Betrieb ist. Warme Luft wird durch die Blende in der Nähe des Ofentürgriffs ausgeblasen. Nachdem der Backofen ausgeschaltet wurde, läuft der Ventilator möglicherweise noch weiter, um die Bedienelemente zu kühlen. Das ist normal.



Wie lange der Ventilator weiterläuft, richtet sich danach, wie lange der Backofen in Betrieb war und welche Temperatur gewählt wurde. Bei niedrigeren Temperatureinstellungen schaltet sich der Ventilator möglicherweise gar nicht ein, oder er läuft nicht weiter, wenn der Backofen nur kurzzeitig in Betrieb war.

## **Praktische Tipps**



# Beim Garen die Backofentür immer geschlossen halten.

Dieser Ofen ist mit einem exklusiven Garsystem ausgestattet, das einen natürlichen Luftstrom erzeugt und die Kochdämpfe kon-tinuierlich in Umlauf bringt.

Das Garen der Speisen erfolgt somit in einer ständig feuchten Umgebung, welche die Spei-sen innen zart und außen knusprig gart. Die Garzeiten und der Energieverbrauch werden auf ein Mindestmaß verringert. Während des Garens wird Dampf erzeugt, der beim Öffnen der Tür austreten kann. Das ist normal



#### Beim Öffnen der Ofentür, während oder am Ende des Garens auf den Heißluft-strom achten, der aus dem Ofen austritt.

Wenn Speisen erhitzt werden, wird Dampf erzeugt wie das in einem Kochkessel geschieht. Wenn der Dampf mit dem Backofen-Türglas in Berührung kommt, kondensierter und es entstehen Wasser-Tröpfchen.

Um Kondensation zu verringern, den leeren Backofen immer 10 Minuten vorheizen!

Wir empfehlen Ihnen, die Wassertropfen nach jedem Garvorgang wegzuwischen.

#### **Ober- und Unterhitze**

Hitze von oben und von unten. Es wird empfohlen die mittlere Einschiebeleiste zu benutzen. Sollte das Gericht mehr Wärme von oben oder von unten benötigen, sobenutzen Sie die oberen oder die unteren Einschiebeleisten.

#### Heißluftbetrieb

Die Wärmeübertragung geschieht hierbei durch heisse Luft, die von dem Lüfterrad in der Backofenrückwand in Bewegung gesetzt wird (Zwangs-Konvektion). Damit verteilt sich die Wärme gleichmäßig und schnell im Backofen. Daher können in den verschiedenen Etagen mehrere Gerichte gleichzeitig gegart werden . Durch die ständige Luftbewegung keine Geruch-oder Geschmacksübertragung findet selbst bei unterschiedlichen Gerichten.

Bei Heissluftbetrieb können bis zu 2 Bleche Kleingebäck gleichzeitig eingeschoben werden. Beim Backen oder Garen in nur einer Etage wird empfohlen, zur besseren Beobachtung, die unteren Einschiebeleisten zu benützen. Heisslufbetrieb eignet sich auch besonders gut zum Sterilisieren und zum Dörren von Pilzen oder Obst

#### Grillen

Alle Fleischarten eignen sich zum Grillen, Ausnahme machen lediglich Wildfleisch und Hackbraten. Fleisch und Fisch werden vor dem Grillen mit Öl bestrichen. Je flacher das Grillgut ist, um so näher am Grillstab grillen und umgekehrt. Der Rost kann mit Wölbung nach oben oder nach unten eingeschoben werden. Um eine gute Bräunung zu erzielen, wird der Rost in die 4. Einschiebeleiste, also dicht unter den Grill geschoben. Mit etwas Wasser in der Fettpfanne wird die Reinigung erleichtert. Fettpfanne in die erste Einschiebeleiste von unten einschieben. Bei jedem Back-, Brat- oder Grillvorgang muss die Backofentür geschlossen bleiben. Während des Backofenbetriebs bleibt die Backofenlampe eingeschaltet.

### Heißluftgrill



Beim Heißluftgrill eine maximale Temperatur von 200°C stellen.

Daraufhin setzt ein abwechselndes Funktionieren von Grill und Ventilator ein (Konvektionsbetrieb). Diese Betriebsweise ermöglicht das gleichmäßige Eindringen der Wärme in das Kochgut, ohne die Oberfläche über zu lange Zeit hinweg der direkten Bestrahlung des Grills auszusetzen.

#### Die Funktion ist besonders geignet für:

die Zubereitung großer Fleischstücke, Geflügel und ganzer Fische wie Forellen. Makrelen oder Meeräschen.

#### Unterhitze

Diese Funktion ist besonders nützlich beim Blindbacken von Teig. Sie kann auch für Quiches oder Pasteten verwendet werden, damit gewährleistet ist, dass der Grundteig durchgebacken ist.

### Oberhitze

Diese Funktion eignet sich zum Überbacken von fertigen Gerichten, zum Beispiel Lasagne oder überbackener Blumenkohl usw.

#### Auftauen

Das Gebläse läuft ohne Hitze und wälzt die Luft bei Raumtemperatur im Garraum um.

Vergewissern Sie sich, dass sich der Temperaturregler in der Position AUS befindet.

#### Pizza

Die kombinierte Wirkung der von unten kommenden Hitze, des Ringheizkörpers und der vom Gebläse verteilten Heißluft ermöglicht das einheitliche Backen von Pizzas oder gesalzenen Torten.

#### Unterhitze

Diese Funktion ist besonders nützlich beim Blindbacken von Teig. Sie kann auch für Quiches oder Pasteten verwendet werden, damit gewährleistet ist, dass der Grundteig durchgebacken ist.

#### Oberhitze

Diese Funktion eignet sich zum Überbacken von fertigen Gerichten, zum Beispiel Lasagne oder überbackener Blumenkohl usw.

#### Auftauen

Das Gebläse läuft ohne Hitze und wälzt die Luft bei Raumtemperatur im Garraum um.

Vergewissern Sie sich, dass sich der Temperaturregler in der Position AUS befindet.

#### **Pizza**

Die kombinierte Wirkung der von unten kommenden Hitze, des Ringheizkörpers und der vom Gebläse verteilten Heißluft ermöglicht das einheitliche Backen von Pizzas oder gesalzenen Torten.

# (i)

## Ratschläge

#### Zum Backen:

Backgut erfordert gewöhnlich eine mässige Temperatur (150-200°C) und daher ist ein Vorheizen des Backofens von ca. 10 Minuten notwendig.

Die Backofentür nicht öffnen, bevor 3/4 der Backzeit abgelaufenist.

Mürbeteig wird in der Springform oder auf dem Blech bis zu 2/3 der Backzeit gebacken und danach garniert, bevor er fertiggebakken wird. Diese weitere Backzeit ist abhängig von der Art und Menge der Garnitur. Rührteige müssen schwer vom Löffel reissen. Die Backzeit würde durch zuviel Flüssigkeit unnötig verlängert werden.

Werden zwei Backbleche mit Gebäck gleichzeitig in den Ofen eingeschoben, muss zwischen den Blechen eine Einschiebeleiste freigelassen werden.

Werden zwei Backbleche mit Gebäck gleichzeitig in den Ofen eingeschoben, müssen die Bleche nach etwa 2/3 der Backzeit von oben nach unten getauscht und gedreht werden.

#### Zum Braten:

Nicht weniger als 1 kg Braten nehmen, klei-nere Stücke könnten beim Braten austrokknen. Dunkles Fleisch, das aussen gut gegart, jedoch innen noch rosa bis rot bleiben soll, muss bei höherer Temperatur (200-250°C) gebraten werden. Helles Fleisch, Geflügel, und Fisch erfordem dagegen eine niedrigere Temperatur (150-175°C). Die Sossenzutaten werden nur bei kurzer Garzeit gleich zu Beginn in die Bratenpfanne gegeben, andemfalls werden sie in der letzten halben Stunde zugegeben.

Ob das Fleisch gar ist, können Sie mit einem Löffel prüfen: lässt es sich nicht eindrücken, so ist es durchgebraten. Roastbeef und Filet, die innen rosa bleiben sollen, müssen bei höherer Temperatur in kürzerer Zeit gebraten werden.

Beim Garen von Fleischgerichten direkt auf dem Rost zum Auffangen des Saftes Fettpfanne in die Leiste unten einschieben.

Den Braten vor dem Anschneiden mindestens 15 Minuten stehen lassen, damit der Fleischsaft nicht ausfliessen kann. Um die Rauchbildung im Backofen zu ver-mindem, empfiehlt es sich, ein wenig Wasser in die Fettpfanne zu giessen. Um Kon-densbildung zu vermeiden, mehrmals Wasser zugeben. Die Teller können bis zum Servieren im Backofen bei Mindesttemperatur warmgehalten werden.



#### Vorsicht!


Den Backofen nicht mit Alufolie auslegen und kein Kochgeschirr, keine Fettpfanne oder Backblech auf den Boden stellen, da sonst das Backofenemail durch den entstehenden Hitzestau beschädigt wird.

#### Garzeiten

Die Garzeiten können unterschiedlich sein, aufgrund der verschiedenen Zusammenset-zung, Zutaten-und Flüssigkeitsmenge der einzelnen Speisen.

Merken Sie sich die Einstelldaten der ersten Koch-bzw. Bratvorgänge, um Erfahrung zu sammeln für die spätere Zubereitung gleicher Gerichte.

Aufgrund Ihrer eigenen Erfahrungen können Sie die angegebenen Werte individuell verändern.





## Back- und Brattabelle

Ober- und Unterhitze sowie Heißluft

Zeitangaben beinhalten kein Vorheizen.
Den leeren Backofen immer 10 Minuten vorheizen.

GERICHT	Ober- und	Unterhitze	Heißluf	t	Garzeit in Minuten	LUNIMEICE
GERIONI	4 3 2 1	Temp. (°C)	3 2 1	Temp. (°C)	0	HINWEISE
KUCHEN Rührteig Mürbeteig Buttermilch-Käsekuchen Apfelkuchen Strudel Marmeladentorte Rührkuchen Biskuitkuchen Stollen Pflaumenkuchen Kleine Kuchen Biskuits Baiser Hefekleingebäck Gebäck: Brandteig Törtchen	2 2 1 1 2 2 2 2 1 1 1 3 2 2 2 2 2 2 2 2	170 170 175 175 180 190 170 170 150 175 170 160 135 200 210 180	2 (1und3)* 2 (1und3)* 2 links+rechts. 2 (1und3)* 2 (1und3)* 2 (1und3)* 2 (1und3)* 2 (1und3)* 2 (1und3)*	160 160 165 160 160 180 150 165 150 160 150 150 170 170	45-60 20-30 60-80 90-120 60-80 40-45 60-70 30-40 120-150 50-60 20-35 20-30 60-90 12~20 25-35 45-70	Kuchenform Kuchenform Kuchenform Kuchenform Backblech Kuchenform Kuchenform Kuchenform Kuchenform Brotpfanne Backblech Backblech Backblech Backblech Backblech Kuchenform
BROT UND PIZZA Weißbrot Roggenbrot Brötchen Pizza	1 1 2 2	195 190 200 200	2 1 2 (1und3)* 2	185 180 175 200	60-70 30-45 25-40 20-30	Brotpfanne Backblech Backblech
FLANS Pasta-Flan Gemüse-Flan Quiches Lasagne Cannelloni FLEISCH	2 2 1 2 2	200 200 210 200 200	2 (1und3)* 2 (1und3)* 1 2 2	175 175 190 200 200	40-50 45-60 30-40 25-35 25-35	Backform Backform Backform Backform Backform
Rind Schwein Kalb	2 2 2	190 180 190	2 2 2	175 175 175	50-70 100-130 90-120	Rost Rost Rost
Englisches Roastbeef rot 2 rosa durch Schweineschulter Schweinshaxe Lamm Hähnchen Truthahn Ente Gans Kaninchen Hase Fasan Hackbraten FISCH	210 22 22 22 22 22 22 22 22 22 22 22 22 22	2 210 210 180 180 190 190 180 175 175 190 190 190 180	200 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	50-60 200 170 160 175 200 160 220 160 175 175 175	Rost 60-70 70-80 120-150 100-120 110-130 70-85 210-240 120-150 150-200 60-80 150-200 90-120 insg 150	Rost Rost mit Schwarte 2 Stck Keule Ganz Ganz komplett komplett In Stücken In Stücken komplett Brotpfanne
FISCH Forelle/Meerbrasse Thunfisch/Lachs	2 2	190 190	2 (1und3)* 2 (1und3)*	175 175	40-55 35-60	3-4 Fische 4-6 Filets

<sup>(\*)</sup> Falls Sie gleichzeitig mehr als ein Gericht garen, empfehlen wir, diese auf den in Klammern angegebenen Ebenen abzustellen.



## Herkömmliches Grillen 👕 - 🚾

(i)

Zeitangaben beinhalten kein Vorheizen.

Den leeren Backofen immer 10 Minuten vorheizen.

GERICHT	Mei	nge	Grillen		Garzeit in Minuten	
	Stück	Gr.	33 22 1	Temp. (°C)	1. Seite	2. Seite
Filetsteaks	4	800	3	250	12~15	12~14
Beefsteaks	4	600	3	250	10~12	6~8
Grillwürste	8	1	3	250	12~15	10~12
Schweinskotelett	4	600	3	250	12~16	12~14
Hähnchen (in 2 Hälften)	2	1000	3	250	30~35	25~30
Spieße	4	1	3	250	10~15	10~12
Hähnchenbrust	4	400	3	250	12~15	12~14
Hamburger*	6	600	2	250	20-30	
*5'00" vorheizen						
Fischfilet	4	400	3	250	12~14	10~12
Belegte Toastbrote	4~6	1	3	250	5~7	1
Weißbrotscheiben	4~6	1	3	250	2~4	2~3

### Umluftgrill 【業】

A

Wählen Sie bei Verwendung der Heißluftfunktion eine Höchsttemperatur von 200°C.

GERICHT	Mer	nge 	Umluftgrill 🗶		Garzeit in Minuten	
	Stück	G.	43 2 1	Temp. (°C)	1. Seite	2. Seite
Rouladen (Pute)	1	1000	3	200	30~40	20~30
Hähnchen (halbiert)	2	1000	3	200	25~30	20~30
Hähnchenschenkel	6	_	3	200	15~20	15~18
Wachtel	4	500	3	200	25~30	20~25
Gemüsegratin	_	_	3	200	20~25	_
St. Jacques Muscheln	_	_	3	200	15~20	_
Makrelen	2-4	_	3	200	15~20	10~15
Fischscheiben	4-6	800	3	200	12~15	8~10

## Pizza-Funktion (&)

GERICHT	Pizza-Funktion (💫		Garzeit in Minuten	ANM.
<u> </u>	3 2 1	Temp. (°C)		,
Pizza, groß	1	200	15~25	Backblech
Pizza, klein	1	200	10~20	Backblech oder Rost
Brötchen	1	200	15~25	Backblech



Die angegebenen Temperaturen sind Richtwerte. Die Temperatur ist unter Umständen persönlichen Ansprüchen anzupassen.

# Reinigung und Wartung



Vor dem Reinigen den Backofen ausschalten und abkühlen lassen.

Das Gerät darf nicht mit einem Heißdampf oder Dampfstrahlreiniger gereinigt werden.

Wichtig: Vor jeder Reinigungsarbeit das Gerät unbedingt spannungslos machen.

Für eine lange Lebensdauer des Gerätes ist es nötig, regelmäßig folgende Reinigungsarbeiten vorzunehmen:

- Durchführung nur bei abgekühltem Backofen.
- Die emaillierten Teile mit Seifenlauge reinigen.
- Keine Scheuermittel verwenden.
- Edelstahlteile und Glasscheiben mit einem weichen Tuch trockenreiben.
- Bei hartnäckigen Flecken handelsübliche Reinigungsmittel für Edelstahl oder warmen Essig benutzen.

Die Emaillierung des Backofens ist äußerst haltbar und weitgehenst unempfindlich. Die Einwirkung von heißen Fruchtsäuren (Zitronen, Pflaumen oder ähnliches) können jedoch auf der Emailoberfläche belibende, matte und rauhe Flecken hinterlassen. Solche Flecken in der Hochglanzoberfläche der Emaille beeinträchtigen die Funktion des Backofens jedoch nicht. Reinigen Sie den Backofen grundsätzlich nach jedem Gebrauch. Verschmutzungen lassen sich so am leichtesten entfernen. Ein weiteres Einbrennen wird damit vermieden.

### Reinigungsmittel

Kontrollieren Sie vor der Verwendung von Reinigungsmitteln immer, ob diese für Ihren Ofen geeignet sind und vom Hersteller empfohlen werden.

Reinigungsmittel, die Bleiche enthalten, sollten NIE verwendet werden, da sie die Oberflächenbehandlung stumpf werden lassen. Vermeiden Sie ebenso die Verwendung von Scheuermitteln.

### Reinigung der Außenseiten

Wischen Sie regelmäßig die Bedienblende, die Backofentür und die Türdichtungen mit einem weichen Lappen ab, den Sie in warmem Wasser mit etwas flüssigem Reinigungsmittel angefeuchtet haben.

Verwenden Sie zur Vermeidung von Beschädigungen

der Backofenglastür auf keinen Fall:

- Haushaltsreinigungsmittel und Bleichlauge
- imprägnierte Reinigungschwämme, die für Kochtöpfe mit Antihaftbeschichtung ungeeignet sind
- Metallschwämmchen
- Chemische Ofenreiniger oder Sprühdosen
- Rostentferner
- Waschbecken-/Spülen Fleckentferner

Reinigen Sie die Außen- und Innenseite der Glastür mit warmem Seifenwasser. Sollte die Innenseite der Glastür stark verschmutzt sein, benutzen Sie Reinigungsprodukte wie 'Hob Brite'. Benutzen Sie keine Schaber, um den Schmutz zu entfernen.

#### Garraum

Der Emailleboden des Garraums lässt sich am Besten reinigen, wenn der Backofen noch warm ist.

Wischen Sie ihn nach jedem Backofengebrauch mit einem weichen in Seifenwasser angefeuchteten Schwamm aus. Von Zeit zu Zeit ist jedoch mithilfe eines speziellen Reinigungsmittels für Backöfen eine gründlichere Reinigung erforderlich.

### Grill-Heizkörper

Bei diesem Modell ist der Grill abklappbar, sodass die Backofendecke besonders einfach zu reinigen ist.




Vergewissern Sie sich zuvor, dass der Herd abgekühlt und von der Stromversorgung getrennt ist.

- Lösen Sie die Schraube, mit der das Grillelement fixiert ist (siehe Abb.). Wenn Sie dies zum ersten Mal tun, empfiehlt es sich, einen Schraubenzieher zu benutzen.
- Ziehen Sie das Grillelement dann vorsichtig nach unten, sodass die Backofendecke zugänglich wird (siehe Abb.).
- Reinigen Sie die Backofendecke mit einem geeigneten Reinigungsmittel und trocknen Sie sie, bevor Sie das abklappbare Grillelement wieder in die Ausgangsposition bringen.
- Drücken Sie das Grillelement vorsichtig nach oben an die ursprüngliche Stelle und schrauben Sie die Haltemutter wieder gut fest.



Vergewissern Sie sich, dass die Haltemutter am Grillelement ordnungsgemäß festgezogen ist, damit es bei Gebrauch nicht herunterfallen kann.



### Reinigung der Backofen-Tür

Bauen Sie die Ofentür aus, bevor Sie mit der Reinigung beginnen.

Gehen Sie hierzu folgendermaßen vor:

- 1. Öffnen Sie die Backofentür vollständig.
- 2. Suchen Sie die Scharniere, mit denen die Tür am Backofen befestigt ist (Abb. A).
- 3. Entriegeln Sie die kleinen Hebel an den beiden Scharnieren (Abb. B) und drehen Sie diese.
- Fassen Sie die Tür an ihrer linken und rechten Seite an und klappen Sie sie dann langsam in Richtung Backofen, bis sie halb geschlossen ist (Abb. C).
- Ziehen Sie die Ofentür dann vorsichtig heraus (Abb. C).
- 6. Legen Sie die Tür auf eine ebene Oberfläche.

Reinigen Sie die Ofentürscheiben nur mit warmem Seifenwasser und einem weichen Tuch. Vewenden Sie dazu niemals Scheuermittel. Bauen Sie nach dem Reinigen die Ofentür wieder ein und gehen Sie dabei in umgekehrter Reihenfolge vor.

#### Geräte mit Edelstahl- oder Aluminiumoberflächen


Wir empfehlen, die Ofentür nur mit einem feuchten Schwamm zu reinigen und danach mit einem weichen Tuch trocken zu wischen.

Verwenden Sie nie Stahlwolle, Säuren oder Scheuermittel, die die Oberflächen beschädigen können. Reinigen Sie die Bedienblende auf dieselbe Weise.



REINIGEN Sie die Backofentür NICHT, solange die Scheiben noch warm sind. Bei Missachtung dieser Anweisung kann die Glasscheibe zersplittern.

Falls die Glasscheibe Risse oder tiefe Kratzer aufweist, ist die Struktur des Glases beeinträchtigt und die Scheibe muss wegen des möglichen Risikos der Zersplitterung ersetzt werden. Wenden Sie sich an den lokalen Kundendienst, der Ihnen gem weiter hilft.



### Ofenroste und Rostauflagen

#### Einschubgitter


Zur Reinigung der Seitenwände lassen sich die Einschubgitter auf der linken und rechten Seite im Backofen abnehmen.

#### Einschubgitter abnehmen

Gitter zuerst vorne von der Backofenwand wegziehen und dann hinten aushängen (19, 20).

#### Einschubgitter einsetzen

Zum Einbau Gitter zuerst hinten wieder einhängen und dann vorne anlegen und andrücken (21). Tauchen Sie die Einschubgitter zum Reinigen in warmes Seifenwasser und entfernen Sie hartnäckigen Schmutz mit einem gut eingeseiften imprägnierten Schwamm. Gut nachwischen und mit einem weichen Tuch trocken wischen.



## Auswechseln der Backofen-Glühlampe

Ziehen Sie den Netzstecker.


Beim Auswechseln der Backofen-Glühlampe sollten Sie darauf achten, dass die neue Lampe folgende Merkmale aufweist:

- Elektrische Leistung: 25 W,
- Elektrische Spannung: 230 V, 50 Hz,
- Hitzebeständigkeit von 300 °C,
- Anschlussart: E14.

Ersatzlampen können Sie bei Ihrem Fachhändler beziehen.

Auswechseln einer schadhaften Backofen-Glühlampe:

- 1. Vergewissern Sie sich, dass der Herd abgekühlt ist.
- Drücken Sie die Glashaube nach innen und schrauben Sie sie entgegen dem Uhrzeigersinn ab.
- 3. Entfernen Sie die durchgebrannte Lampe und setzen Sie eine neue ein.
- Bringen Sie die Glashaube wieder an und stecken Sie den Netzstecker des Backofens wieder in die Steckdose.





# Was tun wenn etwas falsch läuft

Wenn das Gerät nicht richtig arbeitet, bitte vor Anforderung des Electrolux Service-Centers folgendes überprüfen:

FEHLER	ABHILFE
■ Der Backofen schaltet nicht ein.	<ul> <li>◆ Kontrollieren Sie:</li> <li>Hat die Sicherung in der Hausinstallation ausgelöst?</li> <li>Ist die Kindersicherung oder die Ein/Abschaltautomatik eingeschaltet?</li> <li>Hat die Betriebsdauerbegrenzung für den Backofen angesprochen?</li> <li>Ist der "DEMO"-Mode eingestellt? Siehe Kapitel "Demo Funktion ausschalten".         oder</li> <li>◆ Prüfen, ob das Gerät ordentlich angeschlossen ist und der Steckdosen-Schalter oder die Netzstromzufuhr zum Backofen auf EIN stehen.</li> </ul>
■ Die Ofenthermostatanzeige leuchtet nicht.	Stellen Sie mit dem Temperaturregler für den Thermostat eine gewünschte Temperatur ein.     oder     Stellen Sie mit dem Ofenfunktionsschalter eine Garfunktion ein.
■ Die Backofen-Glühlampe brennt nicht.	◆ Stellen Sie mit dem Temperaturregler für den Thermostat eine gewünschte Temperatur ein, oder  ◆ Überprüfen Sie die Lampe und wechseln Sie sie gegebenenfalls aus (siehe "Reinigung des Backofens")
Die Zubereitung der Gerichte dauert zu lange oder sie garen zu schnell.	<ul> <li>Es kann sein, dass die Temperatur eingestellt werden muss, oder</li> <li>Ziehen Sie den Inhalt dieser Anleitung zu Rate, besonders das Kapitel "Praktische Tipps"</li> </ul>
Dampf und Kondenswasser setzen sich auf den Speisen und in der Backofenmuffel ab.	◆Wenn der Garvorgang beendet ist, die Gerichte nicht länger als 15-20 Minuten im Backofen stehenlassen.
■ Fehlercode "F" wird auf dem Display angezeigt.	◆ Notieren Sie den Fehlercode und wenden Sie sich an den lokalen Kundendienst.

## **Technische Daten**

Unterhitze	1000 W
Oberhitze	800 W
Ober-/Unterhitze	1800 W
Grill	1650 W
Doppelgrill	2450 W
Umluftgrill	1675 W
Heissluft - Beheizung	2000 W
Pizza Funktion	3000 W
Backofen-Lampe	25 W
Motor des Heißluftgebläses	25 W
Motor der Kühlungsbelüftung	25 W
Gesamtanschlusswert	3075 W
Betriebsspannung (50 Hz)	230 V ~ / 400 V ~ 3N

Das Gerät kann mit folgenden Einbau-Kochmulden bzw. Glaskeramik-Einbau-Kochfeldern kombiniert werden:

#### Glaskeramik-Kochmulde Typen: ZVD 868 (2 Zweikreis-Kochzonen)

Gesamtanschlußwert	kW	7,6
Betriebsspannung (50 Hz)	23	0 V

#### Glaskeramik-Kochmulde Typen: ZK 630 L - ZK 630 F

(2 Zweikreis-Kochzonen)
Gesamtanschlußwert kW 7,6
Betriebsspannung (50 Hz) 230 V

#### Glaskeramik-Kochmulde Typen: ZC 6695 (1 Zweikreis-Kochzone)

Gesamtanschlußwert kW 6,4 Betriebsspannung (50 Hz) 230 V

# Glaskeramik-Kochmulde Typen: ZC 6675 (Kein Zweikreis-Kochzone)

Gesamtanschlußwert kW 5,8 Betriebsspannung (50 Hz) 230 V

## Einbaunische

Höhe	mm 600
Breite	mm 560
Tiefe	mm 550

#### Maximale Nennheizleistung

ı Backofen + Glaskeramik-Kochmulde 10,675 kW

#### **Finsatz**

Höhe	mm 335
Breite	mm 405
Tiefe	mm 410
Backofenkapazität	531

# Anweisungen für den Installateur



Einbau und Installation sind streng unter Beachtung der bestehenden Vorschriften durchzuführen. Jegliche Eingriffe müssen bei ausgeschaltetem Gerät vorgenommen werden. Eingriffe dürfen nur von anerkannten Fachleuten durchgeführt werden.

Die Herstellerfirma lehnt jede Haftung ab, falls die Sicherheitsmaßnahmen nicht beachtet werden.

#### Elektroanschluss

Vor dem Anschluss bitte folgendes beachten:

- Die Sicherung und die Hausinstallation m\u00fcssen auf die max. Belastung des Ger\u00e4tes ausgelegt sein (siehe Typenschild).
- Die Hausinstallation muss mit einem vorschriftsmässigen und den geltenden Vor-schriften entsprechenden Erdanschluss ausgestattet sein.
- Die Steckdose oder der mehrpolige Aus-schalter müssen auch nach erfolgter Instal-lation des Gerätes einfach zu erreichen sein.

Das Gerät wird ohne Netzkabel ausgeliefert, da je nach vorhandener Versorgungsart, ein Anschlusskabel mit normgerechtem Stecker erforderlich ist, welcher auf die auf dem Typenschild angegebene Belastung ausgelegt sein muss. Den Stecker in eine vorschriftsmässige Steckdose stecken.

Als Anschlußleitungen sind, unter Berücksichtigung des jeweils erforderlichen Nennquerschnittes, folgende Typen geeignet:

H07RN-F, H05RN-F, H05RR-F, H05VV-F, H05V2V2-F (T90), H05BB-F.

Wird der Anschluss ohne Stecker vorgenommen, oder ist dieser nicht zugänglich muss zwischen Gerät und Netzleitung ein mehrpoliger Ausschalter (z.B. Sicherungen, LS-Schalter) mit Mindestabstand zwischen den Kontakten von 3 mm angebracht werden. Der Schalter darf den Schutzleiter an keinem Punkt unterbrechen. Der Gelb-grüne Schutzleiter sollte 2-3 cm länger als alle anderen Kabel sein.

Das Anschlusskabel muss jedenfalls so aus-gelegt sein, dass es an keiner Stelle 50°C (über der Raumtemperatur) erreicht.

Nach erfolgtem Anschluss müssen die Heizelemente geprüft werden, indem sie ca. 3 Minuten lang in Betrieb gesetzt werden.

#### Anschluß der Klemmleiste

Das Gerät ist mit einer leicht zugäanglichen 6-poligen Klemmleiste ausgestattet, deren Brücken bereits für den Betrieb bei 400 V mit Nulleiter vorgesehen sind (Abb. 22).

Im Falle von verschiedener Neztpannung müßen die Brücken der Klemmleiste entsprechend dem Schema Abb. 23 umgelegt werden. Der Schutzleiter kommt an

die Klemme ( Kabel nach dem Anschluß an die Klemmleiste mit Zugentlastung befestigen.





Abb. 22





# Elektrische Verbindung mit der Kochmulde



Achtung - Montageanleitung für Kochmulde, Einbauherd oder Schaltkasten beachten!

Dieses Gerät kann mit den im Kapitel "Technischen Daten" angegebenen Kochmulde-Modellen angeschlossen werden. Die Steckdose für die Verbindung der Koch-mulde befindet sich auf dem Herd-Gehäuse. Aus der Einbaukochmulde sind die Verbindungskabel der Heizelemente und das Schutz-leiterkabel herausgeführt; diese Kabel sind mit Steckanschluß versehen. Stecker und Verbindungskabel in die entsprechende Steckdose des Herdes stecken. Die Möglichkeit einer falschen Verbindung ist somit ausgeschlossen.

Die Erzeugerfirma lehnt jede Haftung ab, falls die Sicherheitsmassnahmen nicht beachtet werden.

## Einbau-Anweisungen

Damit ein störungsfreier Betrieb des Einbaugerätes gewährleistet werden kann, müssen die Küchenmöbel oder die Nische, in die das Gerät eingebaut wird, passende Abmessungen haben.

Gemäß den bestehenden Vorschriften müssen alle Teile, die den Berührungsschutz spannungsführender und betriebsisolierter Teile gewährleisten, so befestigt sein, dass sie nicht ohne Werkzeug abgenommen werden können.

Hierzu gehört auch die Befestigung eventueller Abschluss-Seiten am Anfang oder Ende einer Anbaulinie.

Der Berührungsschutz muss auf jeden Fall durch den Einbau sichergestellt sein.

Das Gerät kann mit seiner Rückseite oder einer Seitenwand an höhere Küchenmöbel, Geräte oder Wände angestellt werden. An die andere Seitenwand dürfen jedoch nur andere Geräte oder Möbel mit gleicher Höhe wie das Gerät angestellt werden.




Abb. 24

### Abmessungen des Backofens (Abb. 24)

### Einbau-Anweisungen

Damit ein störungsfreier Betrieb des Einbaugerätes gewährleistet werden kann, müssen die Küchenmöbel oder die Nische, in die das Gerät eingebaut wird, passende Abmessungen haben (Abb. 25).

## Befestigung im Möbel

- Öffnen Sie die Backofentür.
- Befestigen Sie den Ofen mithilfe der vier Abstandhalter im Möbel (Abb. 26 A). Diese passen genau in die Löcher in dem Rahmen. Ziehen Sie anschließend die vier mitgelieferten Holzschrauben (Abb. 26 B) fest.




Abb. 25




Abb. 26

## **Contents**

Warnings and Important Safety Information	33
Description of the appliance	35
Control panel	36
When the oven is first installed	37
Function Symbols	40
Hotplate control knobs	41
Using the Oven	42
Programming the Oven	46
Special Functions	48
Baking and Roasting Tables	51
Cleaning and Maintenance	53
If something is wrong	57
Technical Data	58
Instructions for the Installer	59
Connecting to the electrical supply	
Building In	60
Service and spare parts	61

# Guide to using the user instructions



Safety instructions



Step by step instructions



Hints and Tips



This appliance conforms with the following ECC Directives:

- 2006/95 (Low Voltage Directive);
- 2004/108 (EMC Directive); and subsequent modifications.

## **English**

# **^**

# Marnings and Important Safety Information

Always keep these user instructions with the appliance. Should the appliance be passed on to third persons or sold, or if you leave this appliance behind when you move house, it is very important that the new user has access to these user instructions and the accompanying information.

These warnings are provided for the safety of the users and those living with them. So read them carefully before connecting and/or using the appliance.

#### Installation

- The installation must be performed by a qualified person in accordance with the rules and regulations in force. The individual operations for installing the appliance are described under the instructions for the installer.
- Have the appliance installed and connected by a qualified person with specialist knowledge, who will carry it out in accordance with the directives.
- If any modifications to the power supply are required because of the installation, these should also be carried out by a qualified electrician.
- This appliance is meant to operate with a singlephase or a three-phase connection to 230V electrical supply, or to a doublephase with neutral wire or three phase with neutral wire 400V electrical supply. A polyphasic 400V connection without neutral wire will cause the destruction of the oven and the combined hob.

### Operation

- This oven is designed for cooking foodstuffs; never use it for other purposes.
- When opening the oven door during or at the end of cooking be careful of the stream of hot air, which comes out of the oven.
- Be very careful when using the cooker. The extreme heat of the heating elements makes the shelves and other parts very hot.
- If you should for whatever reason use aluminium foil to cook food in the oven, never allow it to come into direct contact with the floor of the oven.
- When cleaning the oven, proceed with care: never spray anything onto the grease filter (if fitted), the

- heating elements and the thermostat sensor.
- If is dangerous to make modifications of any kind to this appliance or to its specifications.
- During the baking, roasting and grilling process, the oven window and the other parts of the appliance get hot, so children should be kept away from the appliance. Take care, if connecting electrical appliances to sockets near the oven, that cables do not come into contact with hot rings or get caught in the oven door.
- Always use oven gloves to take hot ovenproof dishes or pots out of the oven.
- Regular cleaning prevents the surface material from deteriorating.
- Before cleaning the oven, either turn the power off or pull the mains plug out.
- Make sure that the oven is in the "OFF" position, when the oven is no longer being used.
- The appliance must not be cleaned with a superheated steam cleaner or a steam jet cleaner.
- Do not use abrasive cleaners or sharp metal scrapers. These can scratch the glass in the oven door, which may result in the shattering of the glass.

### **Child Safety**

- This appliance is intended for use by adults. It is dangerous to allow children to use it or play with it.
- Children should be kept away while the oven is working. Also, after you have switched the oven off, it remains hot for a long time.
- This appliance is not intended for use by children or other persons whose physical, sensory or mental capabilities or lack of experience and knowledge

prevents them from using the appliance safely without supervision or instruction by a responsible person to ensure that they can use the appliance safely.


#### **Customer Service**

- Have checks and/or repairs carried out by the manufacturer's service department or by a service department authorised by the manufacturer and use only original spare parts.
- Do not attempt to repair the appliance yourself in the event of malfunctions or damage. Repairs carried out by untrained persons may cause damage or injury.

The symbol on the product or its packaging


indicates that this product is not to be treated as normal household waste. Instead it must be handed over to a collection point for the recycling of electrical and electronic equipment. The correct disposal of this product will help to protect the environment and human health. Environment and health are endangered by incorrect disposal. For more detailed information about recycling of this product, please contact your local town hall, your household waste disposal service or the shop where you purchased the product.

## Description of the appliance




- 1. Control Panel
- 2. Front-Left Cooking Zone Control Knob
- 3. Rear-Left Cooking Zone Control Knob
- 4. Electronic programmer
- 5. Rear-Right Cooking Zone Control Knob
- 6. Front-Right Cooking Zone Control Knob
- 7. Air Vents for Cooling Fan
- 8. Grill
- 9. Oven light
- 10. Oven Fan
- 11. Rating plate

### Oven accessories



## Control panel



#### **Push buttons**

- 1. ON / OFF
- 2. Oven Function Control
- 3. Fast Heat Up Function
- 4. Decreasing Control "\_\_\_" (Time or Temperature)
- 5. Increasing Control "→" (Time or Temperature)
- 6. Minute minder/Cooking duration function/End of cooking function

All the oven functions are controlled by an electronic programmer.

You can select any combination of cooking function, cooking temperature and automatic timing.

#### NOTE

In the event of a power failure, the programmer will keep all the settings (time of day, programme setting or programme in operation) for about 3 minutes. If power fails for a longer time, all the settings will be cancelled. When the power is restored, the numbers in the display will flash, and the clock/timer has to be reset.

#### When the oven is first installed



Remove all packaging, both inside and outside the oven, before using the oven.

When the oven is first connected to the electrical supply, the display will automatically show 12:00 and the symbol ( ) will flash.

Ensure the correct time of day is set before using the oven.

#### To set the correct time of day:

a) while the symbol ▶ is flashing, set the correct time of day by pressing buttons "\_\_ " or "+" (Fig. 1). The time arrow symbol ▶ will disappear about 5 seconds after the correct time is displayed (Fig. 2). b) if the symbol ▶ is not flashing anymore, press button ⚠ twice (Fig. 3).

Then, proceed as described in point a).

#### Before first use

Before using for the first time, the oven should be heated up without food.

To do that, proceed as follows:

- press button () to switch on the oven.
- press button twice and select the
   "Conventional Cooking" function (Fig. 4).
- set the temperature to 250 °C using the increasing push button "+".
- Allow the oven to run **empty** for approximately 45 minutes.
- open a window for ventilation.


This procedure should be repeated with the "Fan Cooking" and "Full Grill" function for approximately 5-10 minutes.



During this time, an unpleasant odour may be emitted. This is absolutely **normal**, and is caused by residues of manufacturing.



Fig. 2





Once this operation is carried out, let the oven cool down, then clean the oven cavity with a soft cloth soaked in warm water to which a little mild washing-up liquid has been added.

Before cooking for the first time, carefully wash the **shelves** and the **baking tray**.



To open the oven door, always hold the handle in the centre (Fig. 5).




Fig.5

#### "On/Off" Push Button

The oven must be switched on before setting any cooking function or programme. When button ① is pressed, the oven symbol will appear in the display, and the oven light will switch on.

To switch off the oven, you can press button ① at any time. Any cooking function or programme will stop, the oven light will switch off and the time display will show the time of day only.

It is possible to switch off the oven at any time.

#### How to select a Cooking Function

- 1) Switch on the oven by pressing the ① button.
- 2) Press button to select the required oven function.


  Each time button is pressed, a cooking symbol will appear in the display and the corresponding cooking.

will appear in the display and the corresponding cooking function number will appear to the left of the currently selected cooking function symbol (Fig. 6).

- 3) If the pre-set temperature is not suitable, press button "\_\_\_" or "+" to adjust the temperature in 5 degree steps.
- as soon as the oven heats up, the thermometer symbol rises slowly , indicating the degree to which the oven is currently heated:

When the required temperature is reached, an acoustic alarm will sound for a short time and the thermometer

symbol | will illuminate permanently.





## How to set the temperature and cooking time

Press button "\_\_" and "+" to increase or decrease the pre-set temperature while the "o" symbol is flashing (Fig. 7). The maximum temperature is 250°C.

Press button "\_\_\_" and "+" to increase or decrease the pre-set cooking time while the symbol ▶ is flashing (Fig. 7).

#### **Safety Thermostat**

To prevent dangerous overheating (through incorrect use of the appliance or defective components), the oven is fitted with a safety thermostat, which interrupts the power supply. The oven switches back on again automatically, when the temperature drops.


Should the safety thermostat trigger due to incorrect use of the appliance, it is enough to remedy the error after the oven has cooled down; if on the other hand, the thermostat triggers because of a defective component, please contact Customer Service.

#### The cooling fan

The cooling fan is designed to cool the oven and the control panel. The fan switches on automatically after a few minutes of cooking. Warm air is blown out through the aperture near the oven door handle. When the oven is switched off, the fan may run on after the oven is switched off to keep the controls cool. This is quite normal.



The action of the cooling fan will depend on how long the oven has been used and at what temperature. It may not switch in at all at lower temperature settings nor run on where the oven has only been used for a short time.



### **Function Symbols**



Fan cooking - This setting allows you to roast or roast and bake simultaneously using any shelf, without flavour transference. Pre-set temperature: 175 °C



Conventional cooking-The heat comes from both the top and bottom element, ensuring even heating inside the oven. Preset temperature: 200 °C



Inner Grill - can be used for grilling small quantities. Pre-set temperature: 250 °C



Thermal Grilling - This function offers an alternative method of cooking food items, normally associated with conventional grilling. The grill element and the oven fan operate together, circulating hot air around the food. Pre-set temperature: 180 °C



Select a maximum temperature of 200°C.



**Pizza Oven**-The bottom element provides direct heat to the base of pizzas, quiches or pies, while the fan ensures air is circulated to cook the pizza toppings or pie fillings. Pre-set temperature: 175 °C



Full Grill - The full grill element will be on. Recommended for large quantities. Pre-set temperature: 250 °C



Bottom heating element-The heat comes from the bottom of the oven only, to allow you to finish your dishes. Pre-set temperature: 250 °C



**Top heating element** - The heat comes from the top of the oven only, to allow you to finish your dishes. Pre-set temperature: 250 °C



**Defrosting**—The oven fan operates without heat and circulates the air, at room temperature, inside the oven. This function is particularly suitable for defrosting delicate food which could be damaged by heat, e.g. cream filled gateaux, iced cakes, pastries, bread and other yeast products.

### Hotplate control knobs

#### Push-Pull control knobs

Some models are provided with push-pull control knobs. These knobs can be completely sunken inside the control panel when the oven is not working.



The control knobs for the hotplates can be found on the oven control panel. The energy regulator of the hotplates can be set by means of a 7-position control knob:

0 = OFF

1 = Minimum

9 = Maximum

The intermediate positions give an increasing heating power.

#### Double circuit cooking zone

### (Check the combination hob list in the "Technical Data" chapter)


If you wish to have the two electric circuits work simultaneously, turn the knob to maximum position 9


and then turn it towards symbol "\( \)". You will hear a click. Now the 2 circuits work together.


Then, you can regulate the power of the cooking zone by turning the control knob anticlockwise.



Carefully supervise cookings with oil or fats, since these types of food can result in a fire, when over-heated.







### Using the oven

The oven is supplied with an exclusive system which produces a natural circulation of air and the constant recycling of steam.

This system makes it possible to cook in a steamy environment and keep the dishes soft inside and crusty outside. Moreover, the cooking time and energy consumption are reduced to a minimum. During cooking steam may be produced which can be released when opening the oven door. This is absolutely normal.



However, always stand back from the oven when opening the oven door during cooking or at the end of it to allow any build up of steam or heat to release.



Attention! - Do not place objects on the oven base and do not cover any part of the oven with aluminium foil while cooking, as this could cause a heat build-up which would affect the baking results and damage the oven enamel. Always place pans, heat-resisting pans and aluminium trays on the shelf which has been inserted in the shelf runners. When food is heated, steam is created, like in a kettle. When the steam comes into contact with the glass in the oven door, it condenses and creates water droplets.

### To reduce condensation, always preheat the empty oven for 10 minutes.

We recommend you wipe the water droplets away after every cooking process.




Always cook with the oven door closed. Stand clear when opening the drop down oven door. **Do not** allow it to fall open - support the door using the door handle, until it is fully open.

The oven has four shelf levels, and is supplied with two shelves. The shelf positions are counted from the bottom of the oven as shown in the diagram.



It is important that these shelves are correctly positioned as shown in the diagram.

Do not place cookware directly on the oven base.



### Fan cooking (&)

The air inside the oven is heated by the element around the fan situated behind the back panel. The fan circulates hot air to maintain an even temperature inside the oven.

The advantages of cooking with this function are:

#### Faster Preheating

As the fan oven quickly reaches temperature, it is not usually necessary to preheat the oven although you may find that you need to allow an extra 5-7 minutes on cooking times. For recipes which require higher temperatures, best results are achieved if the oven is preheated first, e.g. bread, pastries, scones, souffles, etc.

#### Lower Temperatures

Fan oven cooking generally requires lower temperatures than conventional cooking.

Follow the temperatures recommended in the cooking chart. Remember to reduce temperatures by about 20-25 °C for your own recipes which use conventional cooking.

#### Even Heating for Baking

The fan oven has uniform heating on all shelf positions. This means that batches of the same food can be cooked in the oven at the same time. However, the top shelf may brown slightly quicker than the lower one.

This is quite usual. There is no mixing of flavours between dishes.

#### How to use the fan oven

- 1. Switch the oven on.
- Press the Oven Function Control button and select the "Fan Cooking" (4) function.
- If necessary adjust temperature setting using the "+" or "—" buttons.

### Conventional Cooking

- The middle shelf position allows for the best heat distribution. To increase base browning simply lower the shelf position. To increase top browning, raise the shelf position.
- The material and finish of the baking trays and dishes used will affect base browning. Enamelware, dark, heavy or non-stick utensils increase base

browning, while oven glassware, shiny aluminium or polished steel trays reflect the heat away and give less base browning.

- Always place dishes centrally on the shelf to ensure even browning.
- Stand dishes on suitably sized baking trays to prevent spillage onto the base of the oven and make cleaning easier.
- Do not place dishes, tins or baking trays directly on the oven base as it becomes very hot and damage will occur. When using this setting, heat comes from both the top and bottom elements. This allows you to cook on a single level and is particularly suitable for dishes which require extra base browning such as quiches and flans.

Gratins, lasagnes and hotpots which require extra top browning also cook well in the conventional oven.

How to use the conventional oven

- 1. Switch the oven ON.
- Select the Conventional Oven Function by pressing the Oven Function control button until the symbol appears in the display.

  The course of a record or the formula of the course of

### Top oven element only

This function is suitable for finishing cooked dishes, e.g. lasagne, shepherds pie, cauliflower cheese etc.

### Bottom oven element only

This function is particularly useful when blind-baking pastry. It may also be used to finish off quiches or flans to ensure the base pastry is cooked through.

#### Grilling

- Most foods should be placed on the grid in the grill pan to allow maximum circulation of air and to lift the food out of the fats and juices. Food such as fish, liver and kidneys may be placed directly on the grill pan, if preferred.
- Food should be thoroughly dried before grilling to minimise splashing. Brush lean meats and fish lightly with a little oil or melted butter to keep them moist during cooking.

- Accompaniments such as tomatoes and mushrooms may be placed underneath the grid when grilling meats
- When toasting bread, we suggest that the top runner position is used.
- The food should be turned over during cooking, as required.

#### How to use the Full Grill

- 1. Switch the oven ON.
- Select the Full Grill function by pressing the Oven
  Function control button until the symbol
  appears in the display.
- If necessary adjust temperature setting using the "+" or "\_\_\_" buttons.
- Adjust the grid and grill pan runner position to allow for different thicknesses of food. Position the food close to the element for faster cooking and further away for more gentle cooking.

Preheat the grill on a full setting for a few minutes before sealing steaks or toasting. Adjust the heat setting and the shelf as necessary, during cooking.

#### How to use the Inner Grill Element

The inner grill provides quick direct heat to the central area of the grill pan. By using the inner grill element for cooking small quantities, it can help to save energy.

- Switch the oven ON.
- Select the Inner Grill Element by pressing the Oven
  Function control button until the symbol appears on the display.
- If necessary adjust temperature setting using the "+" or "\_\_" buttons.
- Adjust the grid and grill pan runner position to allow for different thicknesses of food and follow the instructions for grilling.

#### How to Use the Thermal Grill



Select a maximum temperature of 200°C.

Thermal grilling offers an alternative method of cooking food items normally associated with conventional grilling. The grill element and the oven fan operate alternately, circulating hot air around the food. The need to check and turn the food is reduced. Thermal grilling helps to

minimise cooking smells in the kitchen.

With the exception of toast and rare steaks, you can thermally grill all the foods you would normally cook under a conventional grill. Cooking is more gentle, therefore food generally takes a little longer to cook with thermal grilling compared with conventional grilling. One of the advantages is that larger quantities can be cooked at the same time.

- Switch the oven ON.
- Select the Thermal Grill Oven Function by pressing the Oven Function control button until the symbol appears on the display.
- If necessary, press "+" or "---" buttons to adjust the temperature setting. Select a maximum temperature of 200°C.
- Adjust the grid and grill pan runner position to allow for different thicknesses of food and follow the instructions for grilling.

#### Pizza Oven (%)



The bottom element provides direct heat to the base of pizzas, quiches or pies, while the fan ensures air is circulated to cook the pizza toppings or pie fillings.

To obtain the best results use the lower shelf levels.

- 1. Switch the oven ON.
- Select the Pizza Oven Function by pressing the Oven Function control button until the symbol
   appears on the display.
- 3. If necessary, press "+" or "-" buttons to adjust the temperature setting.

### Defrosting 🙏

The oven fan operates without heat and circulates the air, at room temperature, inside the oven. This increases the speed of defrosting. However, please note that the temperature of the kitchen will influence the speed of defrosting. This function is particularly suitable for defrosting delicate food which could be damaged by heat, e.g. cream filled gateaux, iced cakes, pastries, bread and other yeast products.

How to Use Defrosting

- 1) Switch the oven on by pressing button (1).
- Select the Defrosting Oven Function by pressing the Oven Function control button until the symbol
  - appears in the display.
- 3) The display will show the indication "def".

### (i) Hints and Tips

#### On baking:

Cakes and pastries usually require a medium temperature (150°C-200°C) and therefore it is necessary to preheat the oven for about 10 minutes.

Do not open the oven door before 3/4 of the baking time has elapsed.

Shortcrust pastry is baked in a springform tin or on a tray for up to 2/3 of the baking time and then garnished before being fully baked. This further baking time depends on the type and amount of topping or filling. Sponge mixtures must separate with difficulty from the spoon. The baking time would be unnecessarily extended by too much liquid.

If two baking trays with pastries or biscuits are inserted into the oven at the same time, a shelf level must be left free between the trays.

If two baking trays with pastries or biscuits are inserted into the oven at the same time, the trays must be swapped and turned around after about 2/3 of the baking time.

#### On Roasting:

Do not roast joints smaller than 1 kg. Smaller pieces could dry out when roasting. Dark meat, which is to be well done on the outside but remain medium or rare inside, must be roasted at a higher temperature (200°C-250°C).

White meat, poultry and fish, on the other hand, require a lower temperature (150°C-175°C). The ingredients for a sauce or gravy should only be added to the roasting pan right at the beginning if the cooking time is short. Otherwise add them in the last half hour.

You can use a spoon to test whether the meat is cooked: if it cannot be depressed, it is cooked through. Roast beef and fillet, which is to remain pink inside, must be roasted at a higher temperature in a shorter time.

If cooking meat directly on the oven shelf, insert the roasting pan in the shelf level below to catch the juices. Leave the joint to stand for at least 15 minutes, so that the

meat juices do not run out.

To reduce the build up of smoke in the oven, it is recommended to pour a little water in the roasting pan. To prevent condensation forming, add water several times. The plates can be kept warm in the oven at minimum temperature until serving.



#### Caution!

Do not line the oven with aluminium foil and do not place a roasting pan or baking tray on the floor, as otherwise the oven enamel will be damaged by the heat buildup.

#### **Cooking times**

Cooking times can vary according to the different composition, ingredients and amounts of liquid in the individual dishes.

Note the settings of your first cooking or roasting experiments to gain experience for later preparation of the same dishes.

Based upon your own experiences you will be able to alter the values given in the tables.

## ZANIISS

### Programming the Oven

#### How to set the minute minder

- Press button (1) to select the Minute Minder function (Fig. 8). The relevant \(\hat{\Lambda}\) symbol will flash and the control panel will display "0.00".
- 2) Press button "+" to select the required time. Maximum time is 23 hours 59 minutes. After it has been set, the Minute Minder will wait 3 seconds and then start running (Fig. 9).
- 3) When the programmed time has elapsed, an acoustic alarm will be heard.
- 4) To switch off the acoustic alarm, press any button.

The oven will NOT switch off if in use. The Minute Minder function can also be used as well when the oven is off.



#### To use or to change the Minute Minder setting:

press button  $\bigcirc$  until the symbols  $\bigcirc$  and  $\triangleright$  flash. It is now possible to change the Minute Minder setting by pressing button "\_\_" or "+".



press button (→) until the symbols and flash. Press button "\_\_\_" to decrease the time until "0.00" is displayed (Fig. 10).

#### To programme the Oven to switch off

- 1) Place food in the oven, switch on the oven, select a cooking function and adjust the cooking temperature, if required (Fig. 11).
- 2) Press button (1) to select the "Cooking Duration" function (Fig. 12). The "Cooking Duration" symbol will flash and the control panel will display
- 3) While the symbol ▶ is flashing, press button "♣" to select the required time. Maximum time is 23 hours 59 minutes. The programmer will wait 3 seconds and then start running.








Fig. 9








Fig. 12



- 4) When cooking time is over, the oven will be switched off automatically and an acoustic alarm will be heard while the control panel will display "0.00".
- 6) To switch off the acoustic alarm, press any button.


#### To cancel the Cooking Duration Time:


- press button (→) until the symbol ➤ will flash.
- press button "\_\_\_" to decrease the time until "0.00" is displayed (Fig. 13).

## To Programme the Oven to Switch On and Off

- Carry out the "Cooking Duration" setting as described in the relevant chapter.
- 2) Press button until the "End of Cooking" function is selected and the relevant symbol flashes. The control panel will display the end of cooking time (that is, the actual time + cooking duration time Fig. 14).
- Press button "+" to select the required end of cooking time
- 4) After this is set, the programmer will wait 3 seconds and then start running.
- 5) The oven will switch on and off automatically. The end of cooking will be marked by an acoustic alarm.
- 6) To switch off the acoustic alarm, press any button.

To cancel the programme, simply cancel the Duration Time.





### **Special Functions**

#### **Automatic Switch-off Function**

The oven will switch off automatically if any change of setting is made, according to the table below (Fig. 15).

If temperature setting is:	the oven will switch off:
250°C	after 3 hours
from 200 up to 245°C	after 5,5 hours
from 120 up to 195°C	after 8,5 hours
less than 120°C	after 12 hours



Fig. 15

#### **Residual Heat Function**

When a Cooking Duration time is set, the oven will automatically switch off a few minutes before the end of the programmed time, and use the residual heat to finish your dishes without energy consumption. All current settings will be displayed until the Cooking Duration time is over.

This function will not operate when the Cooking Duration time is less than 15 minutes.

#### **Child Lock Function**

To avoid children switching on the oven, it is possible to lock the oven controls.

- 1) Turn off the oven by pressing button ①.
- Press buttons and "—" at the same time and keep them pressed for about 3 seconds. An acoustic signal will be emitted and the indication 'SAFE' will appear on the display (Fig. 16).
- The oven is now locked. Neither oven functions nor temperatures can be selected.

#### To unlock the oven:

Press buttons and "——" at the same time and keep them pressed for about 3 seconds. An acoustic signal will be emitted and the indication 'SAFE' will go off. The oven can now be operated (Fig. 17).




#### "Fast Heat Up" function

After a cooking function has been selected and the temperature has been adjusted, the cavity will gradually heat up until the selected temperature is reached. This will take from 10 to 15 minutes, depending on selected function and temperature.

If it is necessary to reach the required temperature in a shorter time, the "Fast Heat Up" Function can be used.

- 1) Switch the oven on by pressing button ①.
- 2) Set the required cooking function and temperature as explained in the previous pages.
- 3) Set the temperature by pressing button "\_\_\_" or "\\_". The temperature will appear on the display.
- 4) Press button **B**. The temperature display will show "FHU" (Fig. 18).
- 5) press button and the symbol "o" will flash for approximately 10 seconds. Now it is possible to select the required temperature by pressing button "—" or "+".
- 4) When the required temperature is reached, an acoustic alarm will sound for a short time, and the temperature display will revert to the set temperature.

This function can be used with any cooking function or temperature.





#### Demo mode

This mode is intended to be used in shops to demonstrate the oven functionality without any power consumption except the interior light, the display and the fan. This function can only be switched on when the appliance is first connected.

If there is a power failure, when the power supply is restored again, the Demo function can only be switched on if in the display 12:00 and the symbol are flashing automatically.

- 1. Press the button for approximately 2 seconds. An acoustic alarm will sound for a short time.
- 2. Press the and "\_\_"buttons at the same time. A short acoustic alarm will be heard and the time 12:00 will appear in the display (Fig. 19).

When the oven is switched on the symbol appears in the display. This means that the Demo function is activated.

All oven functions can be selected.

The oven is not really working and the heating elements do not switch on.

Switch off the oven and follow the procedure described above to switch off the demo mode again.



The Demo function remains saved in the programme in the event of a power failure.

#### Error code

The electronic programmer does a continuous diagnostic check of the system. If some parameters are not correct, the control unit will stop the activated functions and it will show on the display the corresponding error code (Fig. 20).

For further details, refer to chapter "Something not working".






Fig. 20



### **Baking and Roasting Table**

#### **Conventional Cooking and Fan Cooking**

Timings do not include pre-heating. The empty oven should always be pre-heated for 10 minutes.

TYPE OF DISH	Convention	nal Cooking	Fan Cooki	ng	Cooking times in minutes	NOTES
THE OF BISH	33 22 1	temp °C	4 3 2 1	temp °C		NOTES
CAKES Whisked recipies Shortbread dough Butter-milk cheese cake Apple cake (Apple pie) Strudel Jam- tart Fruit cake Sponge cake Christmas cake Plum cake Small cake Biscuits Meringues Buns Pastry: Choux Plate tarts BREAD AND PIZZA	2 2 1 1 2 2 2 1 1 1 3 2 2 2 2 2 3 7 7 7 7 7 8 7 8 7 8 7 8 7 8 7 8 7 8 7	170 170 175 170 180 190 170 150 175 170 160 135 200 210	2 (1and3)* 2 (1and3)* 2 2lef+righ. 2 2(1and3)* 2 (1and3)* 2 2 2 (1and3)* 2 (1and3)* 2 (1and3)* 2 (1and3)*	160 165 160 160 160 150 150 150 150 170 170	45-60 20-30 60-80 90-120 60-80 40-45 60-70 30-40 120-150 50-60 20-35 20-35 20-30 60-90 12~20 25-35 45-70	In cake mould In cake mould In cake mould In cake mould In baking tray In cake mould In baking tray In cake mould
White bread Rye bread Bread rolls Pizza FLANS	1 1 2 2	195 190 200 200	2 1 2(1and3)* 2	185 180 175 200	60-70 30-45 25-40 20-30	In bread tin In baking tray In baking tray
Pasta flan Vegetable flan Quiches Lasagne Cannelloni MEAT	2 2 1 2 2	200 200 210 200 200	2(1and3)* 2(1and3)* 1 2 2	175 175 190 200 200	40-50 45-60 30-40 25-35 25-35	In mould In mould In mould In mould In mould
Beef Pork Veal	2 2 2	190 180 190	2 2 2	175 175 175	50-70 100-130 90-120	On grid On grid On grid
English roast beef rare medium well done Shoulder of pork Shin of pork Lamb Chicken Turkey Duck Goose Rabbit Hare Pheasant Meat loaf FISH	22222222222222222	210 210 210 180 180 190 190 180 175 175 190 190 180	2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	200 200 200 170 160 175 200 160 220 160 175 175 175	50-60 60-70 70-80 120-150 100-120 110-130 70-85 210-240 120-150 150-200 60-80 150-200 90-120 tot.150	On grid On grid On grid With rind 2 pieces Leg Whole Whole Whole Whole Cut in pieces Cut in pieces Whole in bread pan
Trout/Sea bream Tuna fish/Salmon	2 2	190 190	2(1and3)* 2(1and3)*	175 175	40-55 35-60	3-4 fishes 4-6 fillets

<sup>(\*)</sup> If you cook more than one dish at the same time, we recommend you place them on the levels quoted between brackets.



#### **Conventional Grilling**

Timings do not include pre-heating.

The empty oven should always be pre-heated for 10 minutes.

TYPE OF DISH	Qua	ntity	Grilling		Cooking time in minutes	
	Pieces	g.	4 3 2 1	temp.°C	1st side	2nd side
Fillet steaks	4	800	3	250	12~15	12~14
Beef-steaks	4	600	3	250	10~12	6~8
Sausages	8	1	3	250	12~15	10~12
Pork chops	4	600	3	250	12~16	12~14
Chicken (cut in two)	2	1000	3	250	30~35	25~30
Kebabs	4	1	3	250	10~15	10~12
Chicken (breast)	4	400	3	250	12~15	12~14
Hamburger*	6	600	2	250	20-30	
*Preheat 5'00"						
Fish (fillets)	4	400	3	250	12~14	10~12
Sandwiches	4~6	1	3	250	5~7	1
Toast	4~6	1	3	250	2~4	2~3

### **Thermal Grilling**



With Fan Cooking plus set a maximum temperature of 200°C.

TYPE OF DISH	Qua	ntity	Thermal Grilling X  temp.°C		Cooking time in minutes	
	Pieces	g.			1st side	2nd side
Rolled joints (turkey)	1	1000	3	200	30~40	20~30
Chicken ( cut in two)	2	1000	3	200	25~30	20~30
Chicken legs	6	-3	200 15~20		15~18	
Quail	4	500	3	200	25~30	20~25
Vegetable gratin	-	_	3	200	20~25	
St. Jacques shells	_	-3	200	15~20		
Mackerel	2-4	-3	200	15~20	10~15	
Fish slices	4-6	800	3	200	12~15	8~10

#### **Pizza Function**

TYPE OF DISH	Pizza F	unction 🔼	Cooking time in	NOTES
	4 3 2 1	temp.°C	minutes	
Pizza , large	1	200	15~25	on baking tray
Pizza , small	1	200	10~20	on baking tray or on grid
Bread rolls	1	200	15~25	on baking tray

The temperatures quoted are guidelines. The temperatures may have to be adapted to personal requirements.

### **Cleaning and Maintenance**



Before cleaning switch the oven off and let it cool down.

The appliance must not be cleaned with a superheated steam cleaner or a steam jet cleaner.

**Important:** Before carrying out any cleaning operation, the appliance must be disconnected from the power supply.

To ensure a long life for your appliance, it is necessary to perform the following cleaning operations regularly:

- Only perform when the oven has cooled down.
- Clean the enamelled parts with soapy water.
- Do not use abrasive cleaners.
- Dry the stainless steel parts and glass with a soft cloth.
- If there are stubborn stains, use commercially available for stainless steel or warm vinegar.

The oven's enamel is extremely durable and highly impermeable. The action of hot fruit acids (from lemons, plums or similar) can however leave permanent, dull, rough marks on the surface of the enamel. However such marks in the brightly polished surface of the enamel does not affect the operation of the oven. Clean the oven thoroughly after every use. This is the easiest way to clean dirt off. It prevents dirt being burnt on.

#### Cleaning materials

Before using any cleaning materials on your oven, check that they are suitable and that their use is recommended by the manufacturer.

Cleaners that contain bleach should NOT be used as they may dull the surface finishes. Harsh abrasives should also be avoided.

#### External cleaning

Regularly wipe over the control panel, oven door and door seal using a soft cloth well wrung out in warm water to which a little liquid detergent has been added.

To prevent damaging or weakening the door glass panels avoid the use of the following:

- · Household detergent and bleaches
- Impregnated pads unsuitable for non-stick saucepans
- Steel wool pads
- Chemical oven pads or aerosols
- Rust removers
- Bath/Sink stain removers

Clean the outer and inner door glass using warm soapy water. Should the inner door glass become heavily soiled it is recommended that a cleaning product such as Hob Brite is used. Do not use paint scrapers to remove soilage.

#### **Oven Cavity**

The enamelled base of the oven cavity is best cleaned whilst the oven is still warm.

Wipe the oven over with a soft cloth soaked in warm soapy water after each use. From time to time it will be necessary to do a more thorough cleaning, using a proprietary oven cleaner.

#### **Grill heating element**

This model has been fitted with a hinged grill element to make the roof of the oven especially easy to clean.




Before proceeding ensure the oven is cool and disconnected from the electricity supply.

- Undo the screw fastening the grill element (see Fig).
   When carrying out this operation for the first time, we recommend using a screwdriver.
- 2) Then gently pull the grill downwards to allow access to the oven roof (see Fig).
- Clean the oven roof with a suitable cleaner and wipe dry before returning the hinged grill element to its original position.
- 4) Carefully push the grill element up into its original position and re-tighten the retaining nut.



Ensure the retaining nut on the grill element is properly tightened so that it does not fall down when in use.



#### **Cleaning the Oven Door**

Before cleaning the oven door, we recommend you to remove it from the oven.

#### Proceed as follows:

- open the oven door completely;
- 2. find the hinges linking the door to the oven (Fig. A);
- unlock and turn the small levers located on the two hinges (Fig. B);
- handle the door by its left- and right-hand sides, then slowly turn it towards the oven until it is half-closed (Fig. C);
- 5. gently pull the oven door off its site (Fig. C);
- 6. place it on a steady plan;

Clean the oven door glass with warm soapy water and a softh cloth only. Never use harsh abrasives. Once the cleaning is carried out, refit the oven door, following the procedure in reverse.

#### Stainless steel or aluminium appliances:


We recommend that the oven door is only cleaned using a wet sponge and dried after cleaning with a soft cloth.

Never use steel wool, acids or abrasive products as they can damage the oven surface. Clean the oven control panel following the same precautions.



DO NOT clean the oven door while the glass panels are warm. If this precaution is not observed the glass panel may shatter.

If the door glass panel becomes chipped or has deep scratches, the glass will be weakened and must be replaced to prevent the possibility of the panel shattering. Contact your local Service Centre who will be pleased to advise further.



#### **Oven Shelves and Shelf Supports**

#### Oven shelf support rails


The shelf support rails on the left and right hand sides of the oven can be removed for cleaning the side walls.

#### Removing the shelf support rails

First pull the front of the rail away from the oven wall and then unhitch at the back (21, 22).

#### Fitting the shelf support rails

To install, first reattach the rails at the back, then put them into position at the front and press them into place (23). To clean the shelf support rails, soak in warm soapy water and remove stubborn marks with a well wetted soap impregnated pad. Rinse well and dry with a soft cloth.



#### **Replacing The Oven Light**

Disconnect the appliance

If the oven bulb needs replacing, it must comply with the following specifications:

Electric power: 25 W,

Electric rate: 230 V (50 Hz),


Resistant to temperatures of 300°C,

Connection type: E14.

These bulbs are available from your local Service Force Centre.

To replace the faulty bulb:

- 1. Ensure the oven is isolated from the electrical supply.
- 2. Push in and turn the glass cover anticlockwise.
- Remove the faulty bulb and replace with the new one.
- 4. Refit the glass cover and restore the electrical supply.





### If something is wrong

If the appliance is not working correctly, please check the following before contacting the Electrolux Service Centre:

PROBLEM	SOLUTION
■ The oven is not switching on.	<ul> <li>◆ Touch the</li></ul>
■ The oven light does not come on.	◆ Set the oven function dial to a function.  or  ◆ Buy a new oven light bulb; if necessary, order from the Electrolux Service Centre and install according to the instructions in these User Instructions.
It takes too long to cook the dishes or they cook too quickly.	◆ Following the advice contained in these instructions, especially the section "Practical Tips".
Steam and condensation settle on the food and in the oven cavity.	◆ When the cooking process is completed, do not leave the dishes standing in the oven for longer than 15-20 minutes.
The error code "F appears in the display	◆ Please take note of the error code and pass to our nearest Customer Service office.

10,675 kW

### **Technical Data**

Heating element ration	ngs	This appliance can be connecte ceramic hobs:	d to the below listed
Bottom oven element	1000 W		
Top heating element	800 W	Type: ZVD 868 (with 2 double-circuit cooking z	cones)
Full oven (Top+Bottom)	1800 W	Maximum power absorbed:	7,6 kW
Grill	1650 W	Power supply voltage	(50 Hz) 230 V
Full grill	2450 W	Type: ZK 630 L - ZK 630 F (with 2 double-circuit cooking z	•
Thermal Grill	1675 W	Maximum power absorbed	7,6 kW
Fan Cooking heating	2000 W	Power supply voltage  Type: ZC 6695	(50 Hz) 230 V
Pizza function	3000 W	(with 1 double-circuit cooking 2	,
Oven light	25 W	Maximum power absorbed Power supply voltage	6,4 kW (50 Hz) 230 V
Hot air fan motor	25 W	Type: ZC 6675	
Cooling fan motor	25 W	(without double-circuit cooking Maximum power absorbed	5,8 kW
Total rating	3075 W	Power supply voltage	(50 Hz) 230 V
Operating voltage (50 Hz)	230 V ~ / 400 V ~ 3N	Maximum Total Power Rate	

mm 600

Oven + ceramic hob

#### Dimensions of the recess

Height

riogrit	111111000
Width	mm 560
Depth	mm 550
Oven	
Heigh	mm 335
Width	mm 405
Depth	mm 410
Oven capacity	53

#### Instructions for the Installer



The instructions given below are designed specifically for a qualified installer and should aid him or her to perform all installation, adjustment, and maintenance operations with absolute precision and in compliance with all current legislation and regulations. We strongly recommend that all operations for the installation of your cooker be carryed out by Qualified Personnel in accordance with existing rules and regulations.

**Electrical connection** 

Prior to making the electrical connection, make sure that:

- the protection fuse and the domestic wiring system are suitable to carry the total electric load of the oven (see rating plate);
- your domestic wiring system has an efficient earth connection in compliance with rules and laws in force:
- the wall socket or the omnipole switch used for the electrical connection can easily be reached after the oven is built in.

This appliance is delivered without an electric supply cable, therefore, you will have to fit to it a supply cable with standard plug, suitable for the total electric load shown on the rating plate. The plug is to be inserted into a suitable wall socket. If you require a direct connection to the electric network (mains), it will be necessary to fit between the appliance and the mains an omnipole switch, with a minimum gap between contacts of 3 mm, suitable for the required load and in compliance with rules in torce. The green & yellow ground wire must not be interrupted by the switch, and should be 2-3 cm longer than the phase and neutral wires. The supply cable must in all cases be laid out in such a way as to ensure that it does not reach at any given point a temperature 50°C higher than the ambient temperature.

Suitable power supply cables are the following types, considering the respective necessary section of cable: H07 RN-F, H05 RN-F, H05 RR-F, H05 VV-F, H05 V2V2-F (T90), H05 BB-F.

#### Connecting the terminal board

The appliance incorporates an easily accessible 6-pole terminal board whose jumpers (bridges) are already pre-set for operation on 400 V tri-phase with neutral wire (Fig. 24). In case a different mains voltage is present, the jumpers on the terminal board must be rearranged as shown in the diagram (Fig. 25). The ground cable must be connected to terminal

After connecting the supply cable to the terminal board, secure it with a junction clamp.

#### Electrical connection with the hob

This oven can be connected to hobs indicated in the paragraph "Technical data". The socket for connecting the hob is located at the top of the oven cabinet. The hobs come complete with connecting leads for the hot plates/heat areas and ground cable; these leads feature plug-in connectors. Connection of the hob to the oven is carried out by plugging-in these connectors to the corresponding oven socket.

The plug-to-socket connection design is such as to prevent possible wrong plugging-ins.

The Manufacturer disclaims any liability in case these accident-preventing rules are not observed.




Fig. 24

1	30V 3~ 4x2,5mm²	2 	3  -  L2	4 	5   L3	(E) PE
	30V 1~ 3x2,5mm²	2 I	3 <b>_</b>	4  -   N	5 <b>_</b>	PE
	00V 2N- 4x2,5mm <sup>2</sup>	2  -  2	3 	4  -  N	5 	PE PE
1	00V 3N- 5x1,5mm <sup>2</sup>	2   L2	3   L3	4  -  N	5	(III) PE

Fig. 25

### **Building-in**

To ensure correct operation of the built-in assembly, the kitchen cabinet and the recess for the built-in appliance must have suitable dimensions. When the appliance is fitted-in, there must be no open spaces left and it must be closed on all sides by the kitchen furniture to prevent the possibility of inadvertently touching "live" (current carrying) parts of the oven. All parts ensuring such a protection, including any covering panel (for instance, if the appliance is installed at the end or at the beginning of a kitchen counter) must be fastened in such a way as to prevent removal of the same without the aid of some tool. This appliance can be placed with its back and with one side close to appliances or walls of higher height. The other side, instead, must be placed close to furniture or appliances, having the same height.

## Overall oven dimensions (Fig. 26) Building-in under a kitchen counter

The recess must have the dimensions shown in Fig. 27. Before carrying out the building-in of the oven, connect it to the hob (see corresponding chapter); then recess completely the oven under the counter; open the oven door and secure the oven to the kitchen cabinet.

#### Securing the oven to the cabinet (Fig. 28).

- Fit the appliance into the cabinet recess.
- Open the oven door and secure the oven to the kitchen cabinet by placing the four distance holders (A) in the holes provided in the oven frame and then inserting the four wood screws (B)




Fig. 26




Fig. 27





Fig. 28

### Service and spare parts

If after the checks listed in the chapter "What happens if something goes wrong", the appliance still does not work correctly, contact your local Service Centre, specifying the type of malfunctioning, the appliance model (Mod.), the product number (Prod. No.) and the serial number (Ser. No.) marked on the identification plate. This plate is placed on the front external edge of the oven cavity.

Original spare parts, certified by the product manufacturer and carrying this symbol, are only available at our Service Centre and authorized spare parts shops.

Distriparts





www.electrolux.com www.zanussi.de